




Application Notes

AN12 - INC Static Discharge Upgrade Kit

The INC – Irrigation Network Controller top metal cover is electrically isolated from the metal base because of the thickness of the powder coating. This kit includes an earthing strap that should be connected between the INC Top Cover and Base.

To install this earthing strap, remove all of the green connectors and then prise off the top cover. Position the earthing strap under the screws with the washers provided as shown in the photographs below.



1. One end of the earthing strap goes under the PCB mounting screw next to the fuse on the main PCB.
2. The other end of the earthing strap goes under the LCD mounting screw on the INC cover.

For more information contact Water-Insight support@waterinsight.co.nz